Neptune4

LED修正メモ

1.Add these to your printers home/mks folder. Open Putty and run bash install.sh (Its normal if it returns an oooopsie,just move on) Remove lines in printer.cfg about flashlight and replace with these: [gcode_shell_command hotend] command: sh /home/mks/toggleled.sh timeout: 30. verbose: True

[gcode_shell_command overhead] command: sh /home/mks/toggleovr.sh timeout: 30. verbose: True

[gcode_macro Hotend LED] description: Turn on Hotend LEDs gcode:

```
RUN_SHELL_COMMAND CMD=hotend
```

[gcode_macro Overhead LED] description: Turn on Hotend LEDs gcode:

```
RUN_SHELL_COMMAND CMD=overhead
```

4: Profit

From:
http://deepsky.jp/wiki/ - **うごくといいな**

Permanent link:
http://deepsky.jp/wiki/doku.php?id=memo:3dp:neptune4

Last update: **2025/10/19 19:19**